

How to place/remove the battery into/from a BlueLine controller.

Sometimes the snap-on connector fits very tight the battery.

Please take care when disconnecting the 9v battery to avoid breaking the snap-on connector or tearing off the wires.

A screwdriver or other tool can be used to separate the connector from the battery terminals if required.

Avoid touching both the positive and negative battery terminals at the same time, if using a metal tool, as this will create a short circuit and sparking if the battery is still holding a charge.



1. snap-on and insert the battery



2. put the wire into the slot next to the battery, not on top of the battery